

How to Affix Labels to Vacutainers

Properly Labeled Vacutainers



Improperly Labeled Vacutainers



- Labels should be placed directly below the cap of the tube with the accession number at the top
- Blood bank tubes must have the entire label, date and signature of the Nurse/PCT that draw the sample
- Royal Blue with k2 EDTA OR without should make sure the BD label shows for proper identification of the tube
- Collection time should be written on all tubes
- If any information is written on the BD labels, do not cover it