


 <p><b>1</b></p>	 <p><b>2</b></p>	 <p><b>3</b></p>	 <p><b>4</b></p>
<p><b>1. PIPETTE:</b> Immediately transfer the urine into the <b>cobas</b> PCR Media tube using the provided disposable pipette. <b>NOTE:</b> If the urine specimen cannot be transferred immediately, it can be stored at 2°C to 30°C for up to 24 hours.</p>	<p><b>2. TRANSFER:</b> The correct volume of urine has been added when the fluid level is between the two black lines on the tube label.</p>	<p><b>3. CAP:</b> Tightly re-cap the <b>cobas</b> PCR Media tube.</p>	<p><b>4. MIX:</b> Invert the tube 5 times to mix. The specimen is now ready for transport.</p>